

# 1.Summary

CJE remote control siren is our newly developed electric siren. It has pretty appearance, advanced structure and complete function. This product is suitable for many vehicles. All properties meet as per Stander GB8108-1999.


## 2.Parameter

Item \ Model	CJB	CJB	CJB
Working Voltage	DC10V~14V		
Output Power	100W	150W	200W
Output Impedance	8 Ω	8 Ω	4 Ω
Controller Current	12A×3		
Remote-controlled Distance	Controlled distance ≥20m Microphone's distance ≥10m		
Ambient Temperature	-40℃~+55℃		
Ambient Humidness	≤95%		
AMP Measure	225mm×108mm×51mm		
Controller Measure	105mm×53mm×19mm		
Shell Color	Black		


## 3.Installation

- 1).Amplifier is exothermic, should be install at a ventilated place.
- 2).Controller should be put at a place that easy for user to pick up and away from air bag restraint system.
- 3)Please kindly install according to wiring scheme.

## 4. Wiring Scheme



## 5. Button Instruction



## 6.Usage

### a.How to turn on and turn off the siren

Press down the onoff key could turn the siren on, press again would turn it off, When siren is on work, controller's back light should be on, if there was no operation within 8 seconds, controller will be stand by, back light off. Siren should be turn on again if have to use it.

### b.How to switch the tune

Tap the Tune Switch Button quick, six types tune could be switched.

### c.How to adjust the volume

By pressing the volume button could adjust alarm tune volume.

You could adjust amplified volume by press the volume button under the amplified mode.

You could adjust megaphone volume by press the volume button under the speaking mode.

Each volume of these functions are independent saved.

### d.How to use the light controller

Tap each of the light control button could control each light respectively.

### e.How to switch the horn tune

Press horn button and tune switch button at the same time, could switch one tune to another, and saved it. 7 types tune could be selected.



f.How to use megaphone

You could use speak function by press down the speak button, the red indicator light should be on. Press down again to turn this function off.

g.How to use amplifying function

Press down the RAD button to use amplified function, the green indicator light should be on. Press down again to turn this function off.

h.How to use auto save function

All working state will be saved if it was shut down or powerless; it will be recover when you turn it on next time. (working state includes: alarm tune, volume, horn tune, light controller state ).

i.How to switch the channel

When two controller work within the distance of 30m from siren, recommend to switch one of them to another channel to improve call quality. Press down speak button under siren working state, wait for red indicator light turns on and press down RAD button, the indicator lights on amp and controller will be flashing at the same time, the channel switch completed after flashing stopped. There will be maximum 20 channel works at the same time.

j.How to charge the controller

Controller blue indicator light flashing means powerless, please charge it with car charger or AC power charger.

## 7.Attention

- 1).Please read this instruction before installing and using it.
- 2).Please install the speaker according to instruction, otherwise we do not take responsibility for quality.
- 3).Please be away from horn when turns siren on to avoid scaring.
- 4).Please install it by professional person.
- 5).Please install it at a dry place far from heat sources.
- 6).Please use it with the collocated hand-hold controller.

## 8.Packing List

Item \ Model	CJB-	CJB	CJB
Amplifier	1 pc		
Controller	1 pc		
Connection Wire	1 pc		
Fuse	10A 1pc; 20A 3pcs	15A 1pc; 20A 3pcs	20A 4pcs
Instruction	1 pc		
Warranty Card	1 pc		
Accessory	1 pc		

## 9. Kindly Reminder

Please do not use lightbar and alarm while your car is lay off, or it might trouble you when reset the car

(Battery power will be gone)

Please unplug the siren if you won't use it for at least two weeks.